



WILLOW CREEK GUITARS

www.willowcreekguitars.com

2023-12-13

FXE USER INSTRUCTIONS

The FXE integrated effects processor allows Willow Creek to offer internal effects and Bluetooth. You have complete and independent control of reverbs, chorus and delay that play in the guitar without an amp. Bluetooth is also available to play external sound into the guitar. These effects also pass through to an amplifier. There is a condenser mic with a level control that operates when plugged into an amplifier or PA system to mix with the piezo to warm up the tone. The battery is a rechargeable lithium ion and a charging system is included.

"Volume-BT"

To turn the system on, tap the "Volume" knob. The LED will blink green. To turn on the Bluetooth tap the "Volume" again. The LED will blink blue and green. The pairing name is "MORIN AUDIO AP04B." To turn it off press and hold the "Volume" knob for about three seconds. This knob controls the volume of the internal effects.

"REVERB"

This control is used to set the variable reverb effects. Turning the knob clockwise increases the size of the reverb. Far left is off.

"CHORUS - DELAY"

This knob controls the amount of chorus and delay. The left portion of the knob controls the chorus, the right portion of the knob controls the delay.

"MIC"

This knob controls the volume of the internal condenser microphone. This is only active when the system is plugged into an amp or PA system. Adding some microphone will mix the piezo and microphone to warm up the tone of the guitar. #

